

MERIDIAN

BULK SEED TENDER OPERATOR'S MANUAL



FOR OWNERS OF MODEL SEED TITAN II

PRODUCT WARRANTY REGISTRATION FORM



WARRANTY REGISTRATION

This form must be filled out by the dealer and signed by both the dealer and the customer at the time of delivery. Please mail or fax the completed form for validation of the equipment registration.

Customer's Name _____

Address _____

City, State, Postal Code _____, _____, _____

Phone Number (_____) _____ - _____

PRODUCT INFORMATION

Tender Model # _____

Serial Number # _____

DEALER INSPECTION REPORT

___ Tender frame secured to trailer

___ Check fuel level and gas shut-off

___ Check engine oil level

___ Check reduction case oil level

___ Start Honda engine

___ Brake and lighting harness connection

___ Remote throttle control functions

___ Lubricate unit where necessary

___ Check air pressure in tires

___ Electric brakes in working condition

___ All guards/shields installed correctly

___ All safety signs installed and intact

___ Reflectors and lights clean and working

___ Review safety and operating instructions

___ Inspect customer's hitch for 2-5/16"

ball/gooseneck hitch

___ Verify receipt of all options ordered

I have thoroughly instructed the buyer on the above-described equipment, including review of the Operator's Manual content, equipment care, adjustments, operational use, safety procedures, and applicable warranty policy.

Dealer/Company Name _____

City, State, Postal Code _____, _____, _____

Dealer's Signature _____ Date ____/____/____

The above equipment and Operator's Manual have been received by me, and I have been thoroughly instructed as to care, adjustments, safe operation, and applicable warranty policy.

Owner's Signature _____ Date ____/____/____



2902 Expansion Blvd.
 Storm Lake, IA 50588
 Phone: 712-732-1780
 Fax: 712-732-1028

CERTIFICATE OF ORIGIN

LICENSING INFORMATION

Date: ____/____/____

DEALER:

 Business
 Contact
 Address
 City, State, Zip

SOLD TO:

 Business
 Contact
 Address
 City, State, Zip

TENDER MODEL # _____

TENDER WEIGHT _____

TENDER SERIAL # _____

TRAILER MODEL # _____

TRAILER SERIAL* # _____

TRAILER WEIGHT _____

(*Only one serial number is issued for a complete tender package which will include the trailer. The trailer in these complete packages does not receive a separate serial number.)

Tender 110 BST Wagon	80110	1,004#	Tender T4SE Wagon	80401	2,803#
Tender 110 BST-T (trailer included)	80111	1,830#	Tender T4SE-BWT (trailer included)	80403	4,833#
Tender 220 BST Wagon	80220	1,866#	Tender T4SE-T (trailer included)	80402	4,431#
Tender 220 BST-T (trailer included)	80221	3,495#	T6000ST Trailer	80311	826#
Tender 240RT6 Wagon	80242	2,545#	T14000ST Trailer	80307	1,628#
Tender 240RT6-BWT (trailer included)	80247	4,475#	T21000ST Trailer	80308	2,501#
Tender 240RT6-T (trailer included)	80244	4,174#	Tender 275BH-6DX (trailer included)	80203	4,807#
Tender 240RT8 Wagon	80245	2,604#	Tender 275GN-6DX (trailer included)	80204	5,399#
Tender 240RT8-BWT (trailer included)	80241	4,534#	Tender 275-6DX	80202	4,188#
Tender 240RT8-T (trailer included)	80246	4,232#	Tender 275BH-8DX (trailer included)	80206	4,924#
Tender 240SE-T (trailer included)	80243	4,491#	Tender 275GN-8DX (trailer included)	80207	5,517#
Tender 375RT6 Wagon	80375	3,094#	Tender 275-8DX	80205	4,305#
Tender 375RT6-T (trailer included)	80378	5,636#	Tender 375BH-6DX (trailer included)	80332	5,029#
Tender 375RT6-BWT (trailer included)	80374	5,942#	Tender 375GN-6DX (trailer included)	80333	5,623#
Tender 375RT8 Wagon	80376	3,106#	Tender 375-6DX	80331	4,343#
Tender 375RT8-BWT (trailer included)	80377	5,913#	Tender 375BH-8DX (trailer included)	80335	5,146#
Tender 375RT8-T (trailer included)	80379	5,607#	Tender 375GN-8DX (trailer included)	80336	5,739#
Tender T2SE-T (trailer included)	80201	2,002#	Tender 375-8DX	80334	4,460#
Tender T2-T (trailer included)	80200	1,555#			

Model number for long-reach auger

IMPORTANT INFORMATION

SERIAL NUMBER LOCATION

Please provide the serial number of your Meridian Titan 2 Seed Tender and engine when ordering parts or requesting service or other information.

The serial number plates are located where indicated. Please record the numbers in the space provided below for easy reference.



Seed Tender



Engine

Model Number: Titan 2

Serial Number: _____

Engine Serial Number: _____

PATENT INFORMATION



Meridian continuously enhances its product offering through product improvements and new product innovations. Marketplace feedback, technological innovation, new materials and manufacturing methods, and a philosophy of continuous improvement constantly challenge the company to develop new and better ways of addressing market needs. Meridian is committed to innovation and reinvestment and as a result, the company maintains a portfolio of patents and intellectual property. For more information on our patents please see our website: www.meridianmfg.com/patents

CONTENTS

1. INTRODUCTION	11
1.1 Congratulations	11
1.2 Operator Orientation	11
1.3 Owner/Operator	11
2. SAFETY	12
2.1 General Safety	13
2.2 Equipment Safety Guidelines	14
2.3 Safety Training	14
2.4 Safety Signs	15
2.5 Preparation	15
2.6 Operating Safety	15
2.7 Maintenance Safety	15
2.8 Lock-Out or Tag-Out Safety	15
2.9 Storage Safety	15
2.10 Transport Safety	15
2.11 Refuelling Safety	15
2.12 Battery Safety	15
2.13 Sign-Off Form	16
3. SAFETY SIGN LOCATIONS	17
3.1 General Information	17
3.2 How to Install Safety Signs	17
3.3 Decal Location	17
Long Reach Auger Option	20
4. SPECIFICATIONS	21
4.1 Overall Titan 2 Seed Tender Specifications	21
4.3 Bolt Specifications	22
4.3.1 Bolt Torque Values	22
4.3.2 Grade Markings Chart	22
5. MACHINE COMPONENTS AND CONTROLS	23
5.1 Component Nomenclature and Location	23
5.2 Engine and Controls	24
5.3 Engine Warning Decals	26
6. PRE-OPERATING INSTRUCTIONS	27
6.1 Safety	27
6.2 Machine Break-In Period	27
6.2.1 Before Starting	27
6.2.2 Inspections for 1/2, 5, and 10 Hours	27
6.3 Daily Pre-Operation Checklist	27
7. TOWING	29
7.1 Transport Safety	29
7.2 Connecting the Trailer	29
8. OPERATION	31
8.1 Operating Safety	31
8.2 Loading and Unloading Seed Boxes	31
8.3 Transferring Seed to Planter	34
8.3 Optional Long-Reach Auger Tube	38
8.4 Unplugging Auger Tube	40
9. STORAGE	41
9.1 Storage Safety	41
9.2 General Information	41
9.3 Placing in Storage	41
9.4 Removing from Storage	41

10. MAINTENANCE	42
10.1 Safety	42
10.1.1 General Safety	42
10.1.2 Lock-Out or Tag-Out Safety	42
10.2 Lubrication	43
10.2.1 Wheel Bearings	43
10.2.2 Auger Tube Pivot Shaft	43
10.3 Battery	43
10.3.1 Battery Safety	43
10.3.2 Battery Replacement and Maintenance Tips	44
10.3.3 Battery Maintenance	44
10.4 Engine	45
10.4.1 Refuelling Safety	45
10.4.2 Approved Fuel	45
10.4.3 Engine Oil	45
10.4.4 Change Engine and Reduction Case Oil	45
10.4.5 Clean Air Cleaner	46
10.4.6 Engine Circuit Protection	46
10.5 Engine Actuator Replacement	46
10.5.1 Actuator Removal	46
10.5.2 Actuator Installation	47
10.6 Unplugging Auger Delivery Tube	48
10.7 Auger Drive Belt	49
10.7.1 Drive Belt Tension	49
10.7.2 Drive Belt Installation	49
10.8 Engine Speed Setting	50
10.9 Trailer Break-Away System	51
10.9.1 Testing the Battery	51
10.9.2 Changing Battery	51
10.9.3 Replacing Battery	51
10.10 Wheel Bolt Torque Requirements	51
10.11 Axle Bolts and Frame Hold-Down Bolts	52
10.12 Service Record Chart	53
10.13 Service Checks	54
10.13.1 Daily (8 Hours)	54
10.13.2 Weekly (50 Hours)	54
10.13.3 Annually (400 Hours)	54
10.14 Axle Maintenance	54
10.14.1 First 200 Miles	54
10.14.2 3,000 Miles or 3 Months	54
10.14.3 6,000 Miles or 6 Months	55
10.14.4 12,000 Miles or 12 Months	55
10.15 Tires	55
10.16 Welding Repairs	55
11. OEM LITERATURE	56
11.1 Honda® Engine	56
11.2 Axle	56
12. TROUBLESHOOTING	57
12.1 Troubleshooting Chart	57
13. WARRANTY	58
13.1 Warranty Statement	58

14. PARTS	59
14.1 Titan II Seed Tender	59
14.2 Titan II Seed Tender Frame.	60
14.3 Titan II Engine and Actuator	62
14.4 Titan II Upper Auger Tube	63
14.5 Titan II Lower Auger Tube	64
14.6 Titan II Three Tier Spout	65
14.7 Titan II Trailer	66
14.8 Optional Long-Reach Auger Tube (Middle Section)	67
14.9 Optional Long-Reach Auger Tube (Upper Section).	68

1. INTRODUCTION

1.1 CONGRATULATIONS

Congratulations on your choice of a Meridian Manufacturing Group Titan 2 Bulk Seed Tender to complement your seed delivery system in your farming operation. This equipment has been designed and manufactured to meet the exacting standards for such equipment in the agricultural industry and will keep your seed delivery system at optimum efficiency.



The Bulk Seed Tender system is designed to handle any kind of bulk seed, quickly transport it, and then transfer it into planters and drills, as required.

Safe, efficient, and trouble-free operation of your Bulk Seed Tender requires that you and anyone else who will be operating or maintaining the machine, read and understand the Safety, Operation, Maintenance, and Troubleshooting information contained within this Operator's Manual.

This manual covers the Titan 2 model manufactured by Meridian Manufacturing Group, Inc. Use the Table of Contents and Index as a guide to locate required information.



Standard Auger Configuration

1.2 OPERATOR ORIENTATION

The directions left, right, front, and rear, as mentioned throughout this manual, are as seen from the truck drivers' seat and facing in the direction of travel.

1.3 OWNER/OPERATOR

It is the responsibility of the owner or operator to read this manual and to train all other operators before they start working with the machine. Follow all safety instructions exactly. Safety is everyone's business. By following recommended procedures, a safe working environment is provided for the operator, bystanders, and the area around the work site. Untrained operators are not qualified and must not operate the machine.

In addition to the design and configuration of equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence, and proper training of personnel involved in the operation, transport, maintenance, and storage of equipment. It is the responsibility of the owner or operator to read this manual and to train all operators before they start working with the machine. Follow all safety instructions as laid out in this manual.

Keep this manual handy for easy reference and to pass on to new operators or owners. Call your Meridian Manufacturing Group, Inc. dealer if you need assistance, information, or additional copies of the manuals.

The information, specifications, and illustrations in this manual are those in effect at the time of printing. We reserve the right to change specifications or design at any time without notice.



Long-Reach Auger Configuration

2. SAFETY

SAFETY ALERT SYMBOL

This Safety Alert symbol means
ATTENTION! BECOME ALERT!
YOUR SAFETY IS INVOLVED!



The Safety Alert symbol identifies important safety messages on the Meridian Bulk Seed Tender Models and in the manual. When you see this symbol, be alert to the possibility of personal injury or death. Follow the instructions in the safety message.

WHY IS SAFETY IMPORTANT TO YOU?

3 Big Reasons

- Accidents Disable and Kill •
- Accidents Cost •
- Accidents Can Be Avoided •

SIGNAL WORDS:

Note the use of the signal words **DANGER**, **WARNING**, and **CAUTION** with the safety messages. The appropriate signal word for each message has been selected using the following guidelines:

CAUTION - Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

WARNING - Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.

DANGER - Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations typically for machine components which, for functional purposes, cannot be guarded.

If you have any questions not answered in this manual, require additional copies of the manual, or the manual is damaged, please contact your dealer or Meridian Manufacturing Group, 2902 Expansion Blvd., Storm Lake, Iowa, 50588, toll free 1-800-437-2334, phone (712) 732-1780, or fax (712) 732-1028.

YOU are responsible for the **SAFE** operation and maintenance of your Meridian Manufacturing Group Bulk Seed Tender. **YOU** must ensure that you and anyone else who is going to operate, maintain, or work around the Bulk Seed Tender be familiar with the operating and maintenance procedures and related **SAFETY** information contained in this manual. This manual will take you step-by-step through your working day and alert you to all good safety practices that should be adhered to while operating the Bulk Seed Tender system.

Remember, **YOU** are the key to safety. Good safety practices not only protect you but also the people around you. Make these practices a working part of your safety program. Be certain that **EVERYONE** operating this equipment is familiar with the recommended operating and maintenance procedures and follow all the safety precautions. Most accidents can be prevented. Do not risk injury or death by ignoring good safety practices.

- Bulk Seed Tender system owners must give operating instructions to operators or employees before allowing them to operate the machine, and then annually thereafter per OSHA (Occupational Safety and Health Administration) regulation 1928.57.
- The most important safety feature on this equipment is a **SAFE** operator. It is the operator's responsibility to read and follow **ALL** Safety and Operating instructions in the manual. Most accidents can be avoided.
- A person who has not read and understood all operating and safety instructions is not qualified to operate the machine. An untrained operator exposes himself and bystanders to possible serious injury or death. Always be and stay alert to any possible unsafe operating or maintenance procedures or conditions.
- Do not modify the equipment in any way. Unauthorized modification may impair the function and/or safety of the components and systems and could affect the life of the equipment, possibly invalidating the warranty coverage.
- Think **SAFETY!** Work **SAFELY!**

2.1 GENERAL SAFETY

1.  Read and understand the Operator's Manual and all safety signs before operating, maintaining, adjusting, filling, unloading, or unplugging the Bulk Seed Tender system.
2.  Have a first aid kit available for use should the need arise and know how to use it.
3.  Have a fire extinguisher available for use should the need arise and know how to use it.
4.  Do not allow riders.
5. When working around or operating this equipment, wear appropriate personal protective equipment. This list includes but is not limited to:







 - A hard hat
 - Protective shoes with slip resistant soles
 - Protective goggles, glasses, or face shield
 - Heavy gloves and protective clothing
 - Respirator
6.  Do not allow long hair, loose fitting clothing, or jewelry around equipment.
7.  Install and secure all guards before starting.
8.  Stop engine, remove ignition key, and wait for all moving parts to stop before servicing, repairing, adjusting, loading, filling, or unplugging.
9.   Establish a lock-out or tag-out policy for the work site. Be sure all personnel are trained in and follow all procedures. Lock-out or tag-out all power sources before working around loading/unloading equipment.
10.  Clear the area of people, especially small children, before starting.
11.  Review safety related items annually with all personnel who will be operating, using, or maintaining the Bulk Seed Tender system.

2.2 EQUIPMENT SAFETY GUIDELINES

1. Safety of the operator and bystanders is one of the main concerns in designing and developing a machine. However, every year many accidents occur which could have been avoided by a few seconds of thought and a more careful approach to handling equipment. You, the operator, can avoid many accidents by observing the following precautions in this section. To avoid personal injury or death, study the following precautions and insist those working with you, or for you, follow them.
2. In order to provide a better view, certain photographs or illustrations in this manual may show an assembly with a safety shield removed. However, equipment should never be operated in this condition. Keep all shields in place. If shield removal becomes necessary for repairs, replace the shield prior to use.
3. Never use alcoholic beverages or sedative drugs while operating this equipment. Consult your doctor about operating this machine while taking prescription medications.
4. Under no circumstances should young children be allowed to work with this equipment. Do not allow persons to operate or assemble this unit until they have read this manual and have developed a thorough understanding of the safety precautions and how it works. Review the safety instructions with all users annually.
5. This equipment is dangerous to children and persons unfamiliar with its operation. The operator should be a responsible, properly trained, and physically able person familiar with farm machinery and trained in this equipment's operations. If the elderly are assisting with farm work, their physical limitations need to be recognized and accommodated.
6. Never exceed the limits of a piece of machinery. If its ability to do a job, or to do so safely, is in question - **DON'T TRY IT.**
7. Do not modify the equipment in any way. Unauthorized modification may result in serious injury or death and may impair the function and life of the equipment.

8. In addition to the design and configuration of this implement, including Safety Signs and Safety Equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence, and proper training of personnel involved in the operation, transport, maintenance, and storage of the machine. Refer to Safety Messages and operation instruction in each of the appropriate sections of the auxiliary equipment and machine Manuals. Note all Safety Signs affixed to the auxiliary equipment.

2.3 SAFETY TRAINING

1. Safety is a primary concern in the design and manufacture of our products. Unfortunately, our efforts to provide safe equipment can be wiped out by a single careless act of an operator or bystander.
2. In addition to the design and configuration of equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence, and proper training of personnel involved in the operation, transport, maintenance, and storage of this equipment.
3. The best safety feature is an informed, careful operator. It is the operator's responsibility to read and comply with ALL Safety and Operating instructions in the manual. Accidents can be avoided.
4. Working with unfamiliar equipment can lead to injuries. Read this manual, as well as the manual for your auxiliary equipment, before assembling or operating to acquaint yourself with the machines. If this machine is used by any person other than yourself, it is your responsibility to make certain that the operator reads and understands the operator's manuals and is instructed in safe and proper use.
5. Know your controls and how to immediately stop augers, conveyors, and any other auxiliary equipment in an emergency. Read this manual and the one provided with all auxiliary equipment.
6. Train all new personnel and review instructions frequently with employees. Be certain only a properly trained and physically able person will operate the machinery. A person who has not read and understood all operating and safety instructions is not qualified to operate the machine. An untrained operator exposes himself and bystanders to possible serious injury or death.

2.4 SAFETY SIGNS

Refer to the Safety Signs section for safety information.

2.5 PREPARATION

Refer to the Preparation section for safety information.

2.6 OPERATING SAFETY

Refer to the Operating section for safety information.

2.7 MAINTENANCE SAFETY

Refer to the Maintenance section for safety information.

2.8 LOCK-OUT OR TAG-OUT SAFETY

Refer to the Maintenance section for safety information.

2.9 STORAGE SAFETY

Refer to the Storage section for safety information.

2.10 TRANSPORT SAFETY

Refer to the Towing section for safety information.

2.11 REFUELLING SAFETY

Refer to the Engine section for safety information.

2.12 BATTERY SAFETY

Refer to the Battery section for safety information.

3. SAFETY SIGN LOCATIONS

3.1 GENERAL INFORMATION

The types of safety signs and locations on the equipment are shown in the following pages. Good SAFETY AWARENESS requires that you familiarize yourself with the various safety signs, the type of warning and the area, or a particular function related to that area.

-  If safety signs have been damaged, removed, become illegible, or parts replaced without signs, new signs must be applied.
- Replacement parts that displayed a safety sign should also display the current sign.
- Replacement safety signs (labels) are available from your authorized Dealer Parts Department or the factory at no cost.

3.2 HOW TO INSTALL SAFETY SIGNS

- Be sure that the installation area is clean and dry.
- Be sure temperature is above 50°F (10°C).
- Determine exact position before you remove the backing paper.
- Remove the smallest portion of the split backing paper.
- Align the sign over the specified area and carefully press the small portion with the exposed sticky backing in place.
- Slowly peel back the remaining paper and carefully smooth the remaining portion of the sign in place.
- Small air pockets can be pierced with a pin and smoothed out using a piece of sign backing paper.

3.3 DECAL LOCATION



1. CAUTION — Read and Understand (#19934)

	CAUTION
	
<ul style="list-style-type: none">• Read and understand the Operator's Manual before using. Review safety instructions annually.• Stop engine, remove ignition key, and wait for all moving parts to stop before servicing, repairing, adjusting, loading, filling, or unplugging.• Keep working area clean and free of debris to prevent slipping or tripping.• Do not allow riders on the trailer or frame when transporting.• Only enter seed compartment when it is empty.• Keep hands, feet, hair, and clothing away from moving parts.• Do not place hands, arms, or body between seed box and frame or lid to prevent pinching or crushing. Components can move unexpectedly.• Do not place hands, fingers, or arms between unloading auger tube segments when placing in unloading configuration.• Stay away from overhead power lines. Electrocutation can occur without direct contact.• Install and secure all guards before starting.• Use care when climbing on frame or ladder to prevent slipping or falling.• Do not smoke when refuelling or working around machine.• Fasten frame securely to trailer before transporting.• In two compartment seed tenders, always empty Compartment 2 first to prevent an unbalanced load. An unbalanced load can cause hitch to upend.	
19934	

2 . Product Serial Number Decal (#19984)


Serial# 6720110948768
2897 Expansion Blvd.
Storm Lake, IA 50588
712-737-1780
Made in U.S.A

3. NOTICE — Product Warranty (#18432)

NOTICE

Product Warranty

Meridian Manufacturing Group (hereinafter "Meridian") warrants all products manufactured by it to be free of defect in material and workmanship for a period of (1) year from the date of purchase.

This Meridian warranty does not cover:

1. Accessories supplied by Meridian but manufactured by others. Meridian will facilitate the other manufacturer warranty for the benefit of the purchaser but will not be bound thereby (example: augers, trailers, agitators, etc.).
2. Products that have been altered by anyone other than a Meridian employee or are used by the purchaser for the purposes other than what was intended at time of manufacture or used in excess of the "built specifications".
3. Products that are custom manufactured by Meridian utilizing the purchaser's design which deviates from the Meridian normal production line manufacture or customized features of the products.
4. Malfunction or damages to the product from misuse, negligence, customer alteration, accidents or product abuse due to incoming material or poor material flow ability or lack of required performance or required maintenance (e.g., poor material flow ability caused by incoming wet fertilizer or hot soybean meal, etc.).
5. Loss of time, inconvenience, loss of material, down time or any other consequential damage.
6. Product used for a function that is different than designed intent (e.g., storing soybean meal in grain bin, unacceptable material in the bin such as hot bean meal when product originally designed for other application, etc.).

To activate this warranty, the purchaser must make contact in writing with Meridian within one (1) year of date of purchase. After contact, Meridian has the right to determine the cause and qualify the legitimacy of the claim. Meridian, upon acceptance of a warranty claim shall have a reasonable time to plan any repair or replacement and may effect repair or replacement out of its factory or through contract with a local repair service. If a purchaser after warranty notice is made chooses to make the repair itself, Meridian must approve any expenses before they are incurred to be responsible for customer reimbursement.

Meridian shall be liable on a warranty claim for repair or replacement of any defective products and this is the purchaser's sole and exclusive remedy. Meridian will not be liable for any other or further remedy including claims for personal injury, property damage or consequential damage. The law of the State of Iowa shall govern and any such claim and any issues with regard to the same shall be resolved in the Iowa District Court for Buena Vista County, Iowa.

18432



4. WARNING — Pinch Point (#19956)


WARNING

PINCH POINT HAZARD

Avoid serious injury from pinching or crushing:

- Keep body parts clear of seed boxes and frame when loading.
- Keep bystanders at least 15 ft. (4.5 m) away from loading area.

19956



5. WARNING — Rotating Parts (#19936)

WARNING

ENTANGLEMENT HAZARD

Avoid serious injury or death:

- Do not operate with access door open.
- Do not place hands or fingers near rotating or moving parts.
- Do not operate without guard.
- Stop engine, remove ignition key, and wait for moving parts to stop before performing any work on unit.

19936


6. WARNING — Upending Hazard (#19938)




8. WARNING — Crushing Hazard (#19989)



9. WARNING — Pinch Point (#19935)



7. WARNING — Electrocutation Hazard (#18433)






10. WARNING — Missing Shield (#19937)

⚠ WARNING	
ENTANGLEMENT HAZARD	
	<p>Entanglement with moving parts could cause serious injury or death:</p> <ul style="list-style-type: none"> • Do not operate without guard. • Avoid contact with rotating parts. • Stay clear of moving parts. <p style="text-align: right; font-size: small;">19937</p>

11. WARNING — Missing Shield (#18435)

⚠ DANGER
<p>ENTANGLEMENT HAZARD</p> <p>Guard Has Been Removed.</p>
<p>Entanglement with moving parts will cause serious injury or death:</p> <ul style="list-style-type: none"> • Do not operate without guard. • Install guard before operating. <p style="text-align: right; font-size: small;">18435</p>

Long Reach Auger Option



12. WARNING — Missing Shield (#17509)

⚠ WARNING ⚠			
	<p>CRUSH HAZARD</p> <p>Keep hands and arms clear of conveyor tube when placing it in storage position. Weight of tube will cause crushing injuries.</p>		<p>ELECTROCUTION HAZARD</p> <p>Avoid contact with overhead power lines or electrically powered objects.</p> <ul style="list-style-type: none"> • Be aware of your surroundings when raising or lowering conveyor. • Maintain at least 20 feet between equipment and any electrical hazard. • Contact with electricity can result in serious personal injury or death. <p style="text-align: right; font-size: small;">17509</p>

13. STAND CLEAR (#XXXXX)


<p>WHEN RAISING AUGER STAND CLEAR - SPOUT SHOULD BE SECURED</p>
--

14. WARNING — Pinch Point Hazard (#19935)

⚠ WARNING	
PINCH POINT HAZARD	
<p>To prevent serious injury or death from pinching:</p> <ul style="list-style-type: none"> • Do not place hands, fingers, or arms between unloading auger tube segments when placing in unloading configuration. Segments can move unexpectedly. • Keep others away. <p style="text-align: right; font-size: small;">19935</p>	

4. SPECIFICATIONS

4.1 OVERALL TITAN 2 SEED TENDER SPECIFICATIONS



4.3 BOLT SPECIFICATIONS

⚠ WARNING

EQUIPMENT FAILURE


The torque value for bolts and capscrews are identified by their head markings. Replacing higher “Grade” bolts (Grade 8) with lower Grade bolts (Grade 5) will lead to equipment failure and can result in injury or death. Always use replacement bolts with the same Grade markings as the removed bolt.

4.3.1 Bolt Torque Values

Torque figures indicated above are valid for non-greased or non-oiled threads and heads unless otherwise specified. Therefore, do not grease or oil bolts or capscrews unless otherwise instructed in this manual. When using locking elements, increase torque values by 5%.

Bolt Diameter “A”	SAE Grade 2		SAE Grade 5		SAE Grade 8	
	N·m (ft-lbs)		N·m (ft-lbs)		N·m (ft-lbs)	
1/4"	8	(6)	12	(9)	17	(12)
5/16"	13	(10)	25	(19)	36	(27)
3/8"	27	(20)	45	(33)	63	(45)
7/16"	41	(30)	72	(53)	100	(75)
1/2"	61	(45)	110	(80)	155	(115)
9/16"	95	(70)	155	(115)	220	(165)
5/8"	128	(95)	215	(160)	305	(220)
3/4"	225	(165)	390	(290)	540	(400)
7/8"	230	(170)	570	(420)	880	(650)
1"	345	(225)	850	(630)	1320	(970)

4.3.2 Grade Markings Chart

 No Marking	Grade 2 Low or Medium Carbon Steel
 3 Radial Lines	Grade 5 Medium Carbon Steel Quenched and Tempered
 6 Radial Lines	Grade 8 Medium Carbon Alloy Steel, Quenched and Tempered

5. MACHINE COMPONENTS AND CONTROLS


5.1 COMPONENT NOMENCLATURE AND LOCATION

The Meridian Titan 2 Seed Tender is designed as a bulk seed transfer unit to transport large amounts of seed into a planter or drill.

Large bulk seed boxes are loaded onto the seed tender frame. The center-mounted auger then transfers the seed from the seed boxes into a planter or drill. Slide gates on the unit control the flow of seed into the auger.

Gas engine (9) mounted on the frame powers the auger drive pulley. A reduction case centrifugal clutch (19) on the engine output shaft engages when the engine speed reaches 1400 RPM. The auger belt drive system (31) transmits power from the engine to the auger. Use auger throttle switch (16) to increase or decrease the speed of the auger.

The auger will only unload to the left side. A telescoping spout on the end of the auger allows for convenient distribution.




(1) Safety Chains. (2) Trailer Jack. (3) Break-Away Trailer Brake System. (4) Open/Close Compartment Gate Handles. (5) 12 Volt Battery (inside of frame). (6) Lock-Down Bar Retainer Pin (1 of 4). (7) Discharge Opening Cover (1 of 2).


Once the seed boxes are loaded, the side mounted auger transfers the seed through auger tube (13) and delivery spout (14) into planters or drills. Slide gate levers (4) on the unit control the flow of seed into the auger.




(8) Gas Cylinder (to assist raising auger). (9) Gasoline Engine. (10) Seed Box Frame. (11) Trailer Frame. (12) Document Storage Tube (inside frame). (13) Auger (upper section). (14) Discharge Spout. (15) Retainer Strap. (16) Engine Speed Control Switch. (17) Auger Latch. (18) Handle (for raising/lowering auger).




(19) Centrifugal Clutch Reduction Case. (20) Choke Lever. (21) Fuel Shut-Off Lever. (22) Auger-Speed Actuator (connected to throttle lever). (23) Gas Engine On/Off Controls. (24) Air Filter.



(25) Centrifugal Clutch Gearbox Oil Level. (26) Centrifugal Clutch (speed reduction for belt drive). (27) Fuel Tank. (28) Pull Start Rope. (29) Remote Throttle Switch Auxiliary Plug. (30) Engine Oil Level. (31) Auger Belt Drive and Guard.




(32) Battery Hold Down Strap. (33) Battery.
(34) Electrical System Fuse.



(1) Middle Auger Tube. (2) Upper Auger Tube.
(3) Three Tier Spout. (4) Engine Speed Control Switch.

5.2 ENGINE AND CONTROLS

A Honda® engine is used with this unit. Always read the engine Operator's Manual supplied with the seed tender for the detailed engine operating procedures.



1. Electrical System Key Switch

This key switch controls the power to the electrical system. Turn the key clockwise to turn the electrical system ON. The key will remain in the ON position when the engine is running. Turn the key counterclockwise to stop the engine.

Turn the key switch to the START position to start the engine. When the engine starts, then release the key to allow it to return to the ON position.



2. Starting Rope

This retracting rope and T-bar is an optional method used to start the engine. Turn the key switch to the ON position. Grasp the T-bar firmly and pull the rope sharply to start the engine. The key switch must be in the ON position for the engine to run.

3. Throttle Actuator

The Throttle Actuator is an electronic unit to control the engine speed by a switch mounted at the end of the discharge spout. This allows the person filling the planter boxes to control the output flow of seed.

4. Choke Lever

The choke lever controls the fuel/air mixture to the engine. Close the choke when starting if the engine is cold. Open the choke as the engine warms. Always open the choke fully during operation.


5. Fuel Shut-Off Valve

Each engine is equipped with a valve between the fuel tank and the carburetor. Slide the fuel valve toward the engine to turn ON and away for OFF. Turn the fuel OFF when not in use or before transporting.



6. Engine Circuit Protection


The circuit protector protects the battery charging circuit. A short circuit, or a battery connected with reverse polarity, will trip the circuit breaker. The green indicator inside the circuit protector will pop out to show that the circuit protector has switched off.



8. Auger/Engine Throttle Switch

This two-position toggle switch controls the throttle for the engine. Move the switch to the right to increase the engine speed and to the left to decrease the speed.


Note: The switch can be moved to any convenient location by relocating the switch and wiring harness.



7. Battery (12 Volt)

A 12 Volt battery supplies the power to start the gasoline engine. The battery must be periodically recharged from an external source to keep it fully charged.

5.3 ENGINE WARNING DECALS



1. WARNING — Read Owner's Manual (contact Honda Mfg. for replacement of this decal)




Read Owner's Manual before operation.

2. CAUTION — Shut Off Fuel (contact Honda Mfg. for replacement of this decal)



3. IMPORTANT — Battery Recharging (#19991)



4. CAUTION — Hot Muffler (contact Honda Mfg. for replacement of this decal)



6. PRE-OPERATING INSTRUCTIONS

6.1 SAFETY

-  Never operate the seed delivery system and auxiliary equipment until you have read and completely understand this manual, the auxiliary equipment Operator's Manual, and each of the Safety Messages found on the safety signs on the delivery system and auxiliary equipment.



PROLONGED EXPOSURE TO LOUD NOISE MAY CAUSE PERMANENT HEARING LOSS!

Motors or equipment can be noisy enough to cause permanent or partial hearing loss. We recommend that you wear hearing protection on a full-time basis if the noise in the operator's position exceeds 80db. NOTE: Hearing loss from loud noise (tractors, chain saws, radios, and other such sources close to the ear) is cumulative over a lifetime with uncertain natural recovery.

-  Clear working area of debris, trash, or hidden obstacles that might be hooked or snagged, causing injury, damage, or tripping.
- Operate only in daylight or good artificial light.
- Be sure machine is properly attached to the trailer, adjusted, and in good operating condition.
-  Ensure that all guards, shielding, and safety signs are properly installed and in good condition.
-  Before starting, give the machine a "once over" for any loose bolts, worn parts, cracks, leaks, frayed belts, and make necessary repairs. Always follow maintenance instructions.

6.2 MACHINE BREAK-IN PERIOD

A special break-in procedure has been developed to ensure the integrity of the seed tender when first put into service. Follow the Before Starting instructions and then follow the Inspections for 1/2, 5, and 10 Hours instructions at the appropriate interval.

After completing these instructions, follow the normal service schedule in the Maintenance section and engine manual.

6.2.1 Before Starting

- Read and follow the instructions in the Honda® engine and the Meridian Operator's Manuals.
- Review and follow the Pre-operation Checklist before starting machine.
- Initially check wheel bolt torque and then again at 10, 25, and 50 miles. Refer to the Wheel Bolt Torque Requirements section in this manual for tightening instructions.
- Start the engine and check the controls. Be sure that they function properly.

6.2.2 Inspections for 1/2, 5, and 10 Hours

- Recheck the engine and reduction case fluid levels. Refill, as required.
- Recheck the tension and alignment of the auger tube drive belt.
- Recheck hardware and fasteners; frame to trailer tie-downs, all fasteners, and wheel bolts. Tighten to their specified torque.
- At 10 hours, change the engine oil with the specified oil.

6.3 DAILY PRE-OPERATION CHECK-LIST

Efficient and safe operation of the Meridian Bulk Seed Tender system requires that each operator reads and follows the operating procedures and all related safety precautions outlined in this section.

A preoperational checklist is provided for the operator. It is important for both personal safety and maintaining the efficient operation of the delivery system that this checklist be followed.

Before operating the delivery system and each time thereafter, the following areas should be checked:

- Lubricate the machine, as outlined and shown in the lubrication photos in the Maintenance section of this manual. Follow the prescribed schedule.
- Check the engine fluid levels, fuel, and reduction case oil level. Add, as required.

IMPORTANT

The engine warranty is void if the engine is run without oil.

3. Check the oil level in the engine's centrifugal clutch reduction case.
4. Check hardware and fasteners; seed tender frame to trailer tie-downs, hitch bolts, trailer hitch to trailer bolts, and all other fasteners. Tighten to their specified torque.
5. Make sure the wheel bolt lug nuts are tight.
6. Check the tires and ensure that they are inflated to their specified pressure.
7. Remove all entangled material.
8. Visually inspect the auger, auger tube, and delivery spout for damage.
9. Test the Break-Away brake unit and the trailer brakes.
 - a. Make sure the trailer brakes are operating properly.
 - b. Make sure the trip wire to the break-away switch is connected to the tow vehicle.
 - c. Make sure the pin is correctly installed in the break-away switch.
 - d. Press the Test button. The indicator should illuminate green. If the red light illuminates, the battery charge is low. Refer to the Break-Away System in the Maintenance section for instructions on charging the battery.
10. Check the tension of the auger drive belt. Follow the instructions in the manual to correct the tension and/or alignment.

7. TOWING

7.1 TRANSPORT SAFETY

1.  Comply with local, state, and federal laws governing safety and conveyance of farm machinery on public roads.
2. Ensure all lights, reflectors, and other lighting requirements are installed and in good working condition.
3. Ensure that the trailer is equipped with brakes that are in good working order. Be familiar with their operation.
4. Do not exceed a safe travel speed. Slow down for rough terrain and when cornering.
5.  Fasten frame securely to trailer before transporting.
6. Be sure the trailer is securely hitched to the towing vehicle and a retainer is used through the hitch jaws. Always attach a safety chain between the hitch and the towing vehicle.
7.  Stay away from overhead power lines. Electrocutation can occur without direct contact.
8. Plan your route to avoid heavy traffic.
9. Install auger spout transport lock before transporting.
10. Do not drink and drive.
11. Be a safe and courteous driver. Yield to oncoming traffic in all situations, including narrow bridges, intersections, etc. Watch for traffic when operating near or crossing roadways.
12.  Never allow riders on the tender or the trailer.

7.2 CONNECTING THE TRAILER

WARNING



UPENDING HAZARD

To prevent serious injury or death from upending hazard, do not stand over hitch when unhooking the trailer from the tow vehicle. Load seed box 1 (closest to the hitch) first to keep weight on the hitch. Unload seed box 2 first to keep weight on the hitch.

1. Complete the Pre-operation Checklist.

WARNING



CRUSH HAZARD

Ensure that all bystanders, especially small children, are clear of the working area. Ensure there is enough room and clearance to safely back up to the machine.

2. Use the trailer jack to lift the hitch above the height of the receiver on the tow vehicle (standard hitch assembly shown).



3. Remove the retainer pin. Release or open the receiver by pulling the locking cover back, as shown.



4. Slowly back the tow vehicle until the hitch and ball are aligned.




5. Lower the hitch onto the ball.



6. Raise the jack and place it in its stowed position.



7. Close the receiver by pulling the spring loaded locking collar back to release the hitch mechanism. Install the retainer clip to prevent unwanted opening of the receiver.




8. Attach the safety chain securely to the tow vehicle to prevent unexpected separation. Cross the chains when attaching.



9. Connect the wiring harness for the lights and brakes.

10. Connect the break-away system cable to the tow vehicle. Make sure the key on the end of the cable is properly plugged into the receiving unit.



11. Route all the cables in a manner that will prevent snagging. Be sure to provide slack for turning.

8. OPERATION

8.1 OPERATING SAFETY

-  Make sure that anyone who will be operating the Bulk Seed Tender system or working on or around the unit reads and understands all the operating, maintenance, and safety information in the operator's manual.
-  Keep all bystanders, especially children, away from the machine when loading or unloading, or when authorized personnel are carrying out maintenance work.
-   Establish a lock-out or tag-out policy for the work site. Be sure all personnel are trained in and follow all procedures. Lock-out or tag-out all power sources before servicing the unit or working around loading/unloading equipment.
-  Stop engine, remove ignition key, and wait for all moving parts to stop before servicing, repairing, adjusting, loading, filling, or unplugging.
-   Keep working area clean and free of debris to prevent slipping or tripping.
-  Do not allow riders on the trailer or frame when transporting.
-  Keep hands, feet, hair, and clothing away from rotating parts.
-  Do not place hands, fingers, or arms between moving parts.
-  Stay away from overhead power lines. Electrocution can occur without direct contact.
-  Install and secure all guards before starting.
-  Use care when climbing on frame or ladder to prevent slipping or falling.
-  Fasten frame securely to trailer before transporting.
- Always empty seed box 2 first to prevent an unbalanced load. An unbalanced load can cause the tender to upend.

-  Review safety related items annually with all personnel who will be operating, using, or maintaining the seed delivery system.

8.2 LOADING AND UNLOADING SEED BOXES

The photos in this section represent the correct method for loading and unloading seed boxes from the unit. These photos may not represent the exact seed tender in this manual.


WARNING

UPENDING HAZARD



Always load the front seed box first to maintain a positive tongue weight. Negative tongue weight can cause the hitch to rapidly swing upward if not securely fastened to the tow vehicle, which can result in personal injury.

WARNING



UPENDING HAZARD

To prevent serious injury or death:

- Do not stand over hitch when unhooking unit from tow vehicle.
- **FILLING:** Fill front bin or load front seed box first to maintain downward pressure on hitch.
- **EMPTYING:** Unload or empty rear bin or seed box first to maintain downward pressure on hitch.

19938


WARNING



CRUSH HAZARD

Use caution when lifting seed boxes. A typical seed box can weigh 330 lbs. (150 kg.) when empty. Most seed boxes have the capacity of holding up to 2500 lbs. (1135 kg.) of seed. Keep bystanders away from the loading area and at least 15 ft. (4.5 m) from the seed box. Use a lifting device with a rated lift capacity capable of safely moving the seed boxes.

1. Open the two latch pins.



2. Open both seed box lock-down arms.



3. Remove the two hairpin retainer clips and remove the protective cover. Place the clips back into the retainer studs. Store the cover in a location that prevents it from being damaged.



4. Make sure there are no foreign objects or impacted seed blocking the chute leading to the auger/conveyor.



5. Make sure frame is clear of debris and stand clear when placing the seed box onto the seed tender.



⚠ WARNING


PINCH POINT HAZARD

Avoid serious injury from pinching or crushing:


- **Keep body parts clear of seed boxes and frame when loading.**
- **Keep bystanders at least 15 ft. (4.5 m) away from loading area.**

19956

6. Using a suitable lifting device, carefully place the seed box onto the unit.





7. Make sure the seed box is loaded properly onto the unit.



8. Make sure the rubber boot contacts the bottom of the seed box.





9. Close both seed box lock-down arms.




⚠ WARNING

CRUSH HAZARD
Make sure the latch pins are securely locked to keep the seed box attached to the unit.

10. Lock both latch pins.



11. Open the seed box gate valve.



8.3 TRANSFERRING SEED TO PLANTER

This Operation section provides a step-by-step procedure for first loading seed into the seed tender at the farm and then unloading it in the field.

The seed tender will only unload from the left side.

1. Position the seed tender near the planter.
2. Before unloading, shut off the engine of the tow vehicle, set the parking brake, and remove the ignition key, and wait for all moving parts to stop before leaving the cab.

WARNING



ELECTROCUTION HAZARD
Avoid contact with overhead power lines or electrically powered objects.

1. Be aware of your surroundings when raising or lowering any part of the equipment.
2. Maintain at least 20 feet between the equipment and any electrical hazard.
3. Contact with electricity can result in serious personal injury or death.

3. Check the surrounding area for overhead power lines that would contact the auger tube in its raised position. **Contact with electricity can result in serious personal injury or death.**

WARNING		
	ELECTROCUTION HAZARD	
	Avoid contact with overhead power lines or electrically powered objects.	
<ul style="list-style-type: none"> • Be aware of your surroundings when raising or lowering any part of equipment. 	<ul style="list-style-type: none"> • Maintain at least 20 feet between equipment and any electrical hazard. 	<ul style="list-style-type: none"> • Contact with electricity can result in serious personal injury or death.

4. On standard model augers, make sure the auger cable is threaded into the hole in the end of the auger. Damage to the auger can occur if the cable is not properly inserted.



Note: On long-reach auger models, a spring loaded drive coupling will engage as soon as the auger begins to rotate. Refer to Section 8.3 for additional information.




WARNING



CRUSH HAZARD

Do not raise the upper auger tube when the seed box hold downs are in an open position. Serious injury will result if this instruction is not followed.



WARNING

CRUSHING HAZARD



Avoid serious injury:

- **Close seed box hold-down before raising auger tube.**
- **Secure spout to auger tube before raising.**



19989


5. Pull the auger tube handle outward.



6. Pull the auger tube into the fully open position.



7. Unhook the auger tube retaining strap. Hold the end of the auger tube when releasing the retaining strap to prevent the tube from extending.




8. Place the delivery spout onto the storage bracket.



9. Lock the auger tube sections together using the over-center clamp.




10. Press and hold the remote throttle switch to the right to move the throttle lever 1/3 the distance of the full open position. An electronic actuator is connected to the throttle lever to increase and decrease the speed of the engine.



11. Start the gas engine.


- a. Move fuel valve lever (3) to the ON position.
- b. To start a cold engine, move choke lever (4) to the CLOSED position.



- c. Turn the key switch to the ON position.



12. If necessary, decrease the engine speed below 1400 RPM using the remote throttle control switch. A centrifugal clutch on the engine will engage and rotate the auger when the engine speed exceeds 1400 RPM. Increasing the engine speed will increase the unloading rate.




⚠ WARNING



UPENDING HAZARD

Always unload seed box 2 first to maintain a positive tongue weight. Negative tongue weight can cause the hitch to rapidly swing upward if not securely fastened to the tow vehicle, which can result in personal injury.

⚠ WARNING





UPENDING HAZARD

To prevent serious injury or death:

- **Do not stand over hitch when unhooking unit from tow vehicle.**
- **FILLING:** Fill front bin or load front seed box first to maintain downward pressure on hitch.
- **EMPTYING:** Unload or empty rear bin or seed box first to maintain downward pressure on hitch.

19938

13. Open the slide gate by pushing the handle inward. Close the slide gate by pulling the handle outward.




14. Fill the planting equipment.

- Move the delivery spout to the seed box or bin and increase engine RPM to rotate the auger.
- When the seed box or bin is full, reduce the engine RPM to low idle to stop the auger.
- Move the delivery spout to the next box or bin and increase engine RPM to fill the next one. Repeat this procedure until the remaining boxes or bins are filled.

15. When the planter is filled, close the slide gate and then stop the auger.



16. When the transfer of seed is complete, press the auger speed control switch to reduce the engine RPM and stop the auger.



17. Close the slide gate by pulling the handle outward.

IMPORTANT

If the unit will not be used again for an extended period of time, the auger tube should be cleared of all seed. This will help prevent the seed from being clogged inside the tube.

18. Turn the gas engine off.




19. Place the engine's fuel lever in the OFF position before towing the seed tender on the open road.



20. Before towing the unit on the road, return the auger and auger tube to its stored position. Latch the rubber tie-down strap over the delivery spout.



8.3 Optional Long-Reach Auger Tube



1. Release the retainer strap on upper tube (1) of the auger tube.



2. Open the upper tube and lock it in place with over-center clamp (3).





3. Release the retainer strap on the middle section of the conveyor tube.



4. Remove the rubber retainer strap from the three-tier spout.



5. Use the spout to raise the conveyor.



6. Lock the conveyor tube in place with the over-center clamp.



Note: Both auger tube sections use a spring loaded drive coupling. Even if the couplings are misaligned they will engage with each other once the auger begins to rotate.




7. When not in use, place the end of the spout onto the bracket, as shown.



4. Remove the obstruction.
5. Close and secure the access door.

8.4 UNPLUGGING AUGER TUBE

⚠ WARNING	
ENTANGLEMENT HAZARD	
	Avoid serious injury or death: <ul style="list-style-type: none">• Do not operate with access door open.• Do not place hands or fingers near rotating or moving parts.• Do not operate without guard.• Stop engine, remove ignition key, and wait for moving parts to stop before performing any work on unit. <small>19936</small>
	
	

If the auger tube plugs, follow this procedure.

1. Place the delivery spout on the storage bracket.
2. Stop the engine and remove the ignition key.
3. Open the access door at the bottom of the unloading auger tube.

9. STORAGE

9.1 STORAGE SAFETY

1. Store the unit in an area away from human activity.
2. Do not permit children to play on or around the stored machine.
3. Store the unit in a dry, level area. Support the frame with planks, if required.

9.2 GENERAL INFORMATION

After planting or when the machine will not be used for a period of time, completely inspect all major systems of the seed tender. Replace or repair any worn or damaged components to prevent unnecessary downtime at the beginning of the next season.

IMPORTANT

To prevent component damage, store the seed tender in a dry, level area. If the seed tender is not attached to a trailer, support the frame with planks to raise the unit off the ground.

9.3 PLACING IN STORAGE


CAUTION



PERSONAL INJURY HAZARD
Store the unit in an area away from human activity. To prevent the possibility of serious injury, do not permit children to play on or around the stored machine.

1. Remove all seed from the seed tender.
2. Place the gasoline engine fuel valve in the OFF position.
3. Thoroughly wash the machine with a pressure washer or water hose to remove all dirt, mud, or debris.
4. Inspect rotating parts for entangled material. Remove all entangled materials.
5. Check the condition of the auger and delivery spout. Replace or adjust, as required.
6. Check the condition of the centrifugal clutch reduction case, pulleys, idlers, and drive belt. Replace or adjust, as required.
7. Touch up paint nicks and scratches to prevent rusting.

8. Remove the ignition key and store in a secure place.
9. Remove the battery and store it in a cool, dry area on wooden blocks or a wooden pallet. Charge it monthly to maintain an adequate charge.
10. It is best to store the machine inside and if that is not possible, cover with a waterproof tarp and tie down securely.
11. Inspect, clean, and lubricate the auger tube hinge.



12. Cover the unit with a tarp, if desired.

9.4 REMOVING FROM STORAGE

When removing the machine from storage, follow this procedure:

1. Remove the tarp, if covered.
2. Install and connect the battery.
3. Review and follow the Pre-Operation Checklist.
4. Review and follow the Service Checks in the Maintenance section.

IMPORTANT

If the machine has been stored for more than twelve months, warm the engine by running it for two to three minutes and then drain the oil. Change the oil while the oil is warm to remove any condensation. Refer to the Change Engine and Reduction Case Oil section in the Maintenance section.

10. MAINTENANCE

10.1 SAFETY

10.1.1 General Safety

1. Good maintenance is your responsibility. Poor maintenance is an invitation for trouble.
2. Follow good shop practices. Keep service area clean and dry. Be sure electrical outlets and tools are properly grounded. Use adequate light.
3.  Ensure proper ventilation. Never operate the engine in a closed building. The exhaust fumes may cause asphyxiation.
4.  Before working on this machine, shut off the engine and remove the ignition keys.
5.  Never work under equipment unless it is securely blocked.
6.  Always use personal protection devices, such as eye, hand, and hearing protectors, when performing any service or maintenance.
7.  Where replacement parts are necessary for periodic maintenance and servicing, genuine factory replacement parts must be used to restore your equipment to the original specifications. The manufacturer will not be responsible for injuries or damages caused by use of unapproved parts and/or accessories.
8.  A fire extinguisher and first aid kit should be readily accessible while performing maintenance on this equipment.
9.  Periodically tighten all bolts, nuts, and screws and ensure all cotter pins are properly installed to ensure the unit is in safe condition.
10.  When completing a maintenance or service function, make sure all safety shields and devices are installed before placing the unit in service.

11.  Turn OFF all electrical power and tag-out or lock-out the power source before performing any electrical test or before connecting or disconnecting valve coils or other electrical loads.
12.  Never operate or test any function of the equipment when people are in an area of a potential crush hazard.
13. Disconnect all electronic device cables from the seed tender before performing any arc welding repair. Damage from high currents may cause internal electronic device damage.

10.1.2 Lock-Out or Tag-Out Safety

1.   Establish a formal Lock-Out or Tag-Out program for your operation.
2.  Train all operators and service personnel before allowing them to work around the seed delivery system.
3.  Provide tags on the machine and a sign-up sheet to record tag-out details.

10.2 LUBRICATION

Use the Service Checks information in the Maintenance section to keep a record of all scheduled maintenance.

1. Use an SAE multi-purpose high temperature grease or a multi-purpose lithium base grease for the auger pivot hinge.
2. Use only a handheld grease gun for all greasing.
3. Wipe grease fitting with a clean cloth before greasing to avoid injecting dirt and grit.
4. Replace and repair broken zerks immediately.
5. If zerks will not take grease, remove and clean the passageway. Replace fitting, if necessary.

10.2.1 Wheel Bearings

Each axle is equipped with a grease zerk under the center dust cap of the wheel. Add grease sparingly to the wheel bearings, using only wheel bearing grease. The wheel bearings should be repacked annually. Check for excessive end play and tighten, if necessary.


IMPORTANT

Over greasing wheel bearings can cause them to overheat, resulting in damage and/or failure.



10.2.2 Auger Tube Pivot Shaft

Add grease to the pivot shaft hinge until it is forced out of the joints annually or as needed.



10.3 BATTERY

Inspect the battery at least once every six months and before using the seed tender at the beginning of the season. Always follow the safety instructions when servicing a battery.



10.3.1 Battery Safety

1.  Keep all sparks and flames away from batteries, as gas given off by electrolyte is explosive.
2.  Avoid contact with battery electrolyte: wash off any spilled electrolyte immediately because battery acid can cause severe chemical burns.
3.  Wear safety glasses when working near batteries.
4. Do not tip batteries more than 45 degrees, to avoid electrolyte loss.

5.  To avoid injury from spark or short circuit, disconnect the battery ground cable before servicing any part of the electrical system. Never short circuit the battery. It may explode.
6.  Protect battery terminals, battery-charger terminals, and cables against accidental contact which can cause sparks, explosions, or component damage.
7. Never attempt to jump start a frozen battery.

10.3.2 Battery Replacement and Maintenance Tips


- Check the batteries at least every six months for low Voltage, leakage, etc.
- Always use the correct size and type of battery. Replace old batteries with a new SP-30 Lawn and Garden battery with 230 CCA and 290 CA ratings.
- Do not install the battery cable to the wrong terminal. Make sure the RED cable is connected to the + (plus) terminal and the BLACK cable is connected to the – (minus) terminal.
- Remove the batteries from the seed tender if not expected to be in use for several months.
- Use recommended practices when recharging a dead battery.
- Remove any corrosion from the battery post using a wire brush terminal cleaner. Corrosion can also be removed using a baking soda paste and water to neutralize and remove the acid from the battery terminals
- Dispose of old batteries properly.

10.3.3 Battery Maintenance

1. Make sure the tie-down strap is connected to the frame of the battery box and in good condition (not cracked, cut, or damaged).



2. The battery is not charged when the engine is operating. If the battery is not charging using an external charger, check the fuse. Replace the fuse if necessary.



10.4 ENGINE

For any questions concerning the Honda® engine not provided in this manual, refer to the OEM manual that was provided with the seed tender.

To contact Honda®, refer to the OEM Literature section in this manual.

10.4.1 Refuelling Safety

-  Handle fuel with care. It is highly flammable.
-  Allow engine to cool for five minutes before refuelling. Clean up spilled fuel before restarting engine.
-  Do not refuel the machine while smoking or when near open flame or sparks.
- Fill fuel tank outdoors.
-  Prevent fires by keeping machine clean of accumulated trash, straw, grease, and debris.

10.4.2 Approved Fuel

Use unleaded automotive gasoline for all operating conditions. The fuel tank capacity is 3.6 liters (0.95 gals).


10.4.3 Engine Oil

Use a typical SAE 10W-30 or 10W-40 multi-viscosity motor oil for normal operating conditions. Consult your engine manual for the recommended oil in cold temperatures. The crankcase capacity is 0.60 liters (.63 US qts.).


10.4.4 Change Engine and Reduction Case Oil

- Review the Operator's Manual for the engine.
- Allow the engine to cool before changing the oil. Draining works best when the oil is warm.

- Be sure the engine key switch is in the OFF position and the fuel valve is turned OFF.
- Place a pan under drain plug (1) or (2). Remove the drain plug and allow the oil to drain for ten minutes.



- Reinstall the drain plug and tighten.
- Dispose of the oil in an approved container. Follow industrial disposal regulations.
- Fill the engine or reduction case with SAE 10W-30 oil for general usage. If the engine is operated in more extreme conditions, refer to the OEM manual for oil recommendations.
- Run the engine for one minute and recheck the oil level. Add oil, as needed.




CAUTION



BURN HAZARD
Hot engine oil can burn skin.

10.4.5 Clean Air Cleaner

Check and remove any debris from the foam cover of the air cleaner daily before each use. Thoroughly clean or replace the foam cover every three months or 50 hours of operation (clean it more frequently when used in dusty conditions).



10.4.6 Engine Circuit Protection

The circuit protector protects the battery charging circuit. A short circuit, or a battery connected with reverse polarity, will trip the circuit breaker.

The green indicator inside the circuit protector will pop out to show that the circuit protector has switched off. If this occurs, determine the cause of the problem, and correct it before resetting the circuit protector.

Push the circuit protector button to reset.



10.5 ENGINE ACTUATOR REPLACEMENT

10.5.1 Actuator Removal

WARNING



CRUSHING HAZARD


Ensure the seed tender is blocked to prevent movement.



Ensure the engine is not running and remove the key during the following procedures. Serious injury or death can result from being caught in moving

parts.


1. Remove bolt (1) that secures cover (2) to actuator mounting bracket (3). Remove the cover.




2. Disconnect the actuator cable from the engine harness at connector (4).



- Remove four bolts (5), washers (6), lock nuts (7), and spacers (8).



- Remove washer nut (9) and then disconnect spring (10) from the actuator arm (11).




10.5.2 Actuator Installation

- Connect the cable of the new actuator to engine harness connector (4).
- Position actuator arm (11) so it is pointing away from the end where the cable is attached to the unit, as shown. Use actuator switch (12) on the delivery tube to position the arm.


Note: Do not move the arm manually or the unit will be damaged.




- Place spring (10) onto the pin of actuator arm (11) and install washer nut (9) so the spring is free to rotate on the pin of actuator arm (11).



- Position the actuator onto the mounting bracket so that the four mounting holes are aligned to the bracket (3).
 - Place spacers (8) between the actuator and the bracket. Note that actuator arm (11) is on the same level as the bracket.




- b. If actuator arm (11) is below the bracket (as shown), the arm will continue to rotate and not function properly. The bracket serves as a stop for the arm.




- c. Install four bolts (5), washers (6), and lock nuts (7), as shown. Note that the bolt nearest the engine is reversed for clearance with the lock nut on top.

Note: The four spacers are all positioned under the mounting plate no matter which direction the bolt is installed.



- 5. Reinstall the cover.



- 6. Ensure all personnel are clear of unit. Start the engine and test the actuator by pressing actuator switch (12) to ensure the engine speed increases and decreases as designed.



10.6 UNPLUGGING AUGER DELIVERY TUBE

IMPORTANT

Do not operate the auger when it is plugged with excess seed or is hindered from moving by a foreign object. Continued operation can cause damage.

If the auger becomes plugged, follow this procedure:

1. Stop the engine and remove the ignition key. Place a lock-out tag on the control box to prevent accidental starting of the conveyor.
2. Open the lower access door at the bottom of the auger and remove any excess seed or obstruction.



3. Close and secure the lower access door.



10.7 AUGER DRIVE BELT

The auger is driven by a belt from the motor. The belt is tightened by moving the engine base with the adjusting bolt.

10.7.1 Drive Belt Tension

Release the base when replacing the belt. Always install and secure the guard before resuming work.


1. Loosen the four engine mounting bolts (1).



2. Loosen the engine base stabilizing bolt.



3. Loosen the jam nut on engine base adjusting bolt (2) and move the engine base to set the desired belt tension.



4. Tighten the jam nut.
5. Tighten the four engine mounting bolts.
6. Tighten the engine base stabilizing bolt.

10.7.2 Drive Belt Installation

Use the following photo for the correct routing of the drive belt. Always check the alignment of the pulleys when replacing the belt.



10.8 ENGINE SPEED SETTING

WARNING



ROTATING PART HAZARD


The engine speed must be adjusted with the engine running. Use extreme caution when working near rotating parts.




To prevent serious injury from rotating parts, do not operate with rotating parts exposed. Make sure the belt guard is installed before adjusting the engine speed.

Every engine is set with a high idle of 3000 RPM. Before using the seed tender, check the RPM of the auger drive pulley.


1. Start the engine. Use the throttle switch on the delivery tube to set the engine to high idle (full throttle).



2. Use a tachometer to check the large drive pulley speed. The pulley should turn 200 RPM at high engine speed.



3. Use a screwdriver to reset the high idle stop screw if required to obtain the desired speed.



10.9 TRAILER BREAK-AWAY SYSTEM




10.9.1 Testing the Battery

1. Disconnect the trailer plug from the tow vehicle; otherwise, you are testing the tow vehicle's battery.
2. Press the green TEST button on the control box located inside the frame of the trailer. The green indicator light should illuminate if the battery is fully charged. If the yellow or red indicator lights illuminate, the unit's battery should be charged before towing the trailer.

IMPORTANT

If the battery is weak or dead (red indicator, even after charging), as indicated by the indicator light, the battery must be replaced.

3. Plug the trailer into the tow vehicle. The yellow "Charging" light should be ON.
4. Test the system by pulling the pin out of the break-away switch. The battery will activate the brakes. (**Note:** Do not use this kit as a parking brake). The battery should be charged and tested prior to each trailer outing.



10.9.2 Changing Battery

The battery in the break-away system is rechargeable. If the battery will not hold a charge, replace the battery.

10.9.3 Replacing Battery

The battery in the break-away system is replaceable. If the battery will not hold a charge, replace the battery. Contact the OEM supplier for a replacement battery.



10.10 WHEEL BOLT TORQUE REQUIREMENTS



1. Initially check the wheel bolt torque at 10, 25, and 50 miles and after each wheel removal. Refer to the Wheel Bolt Torque Requirements section in this manual for tightening instructions.

Note: Torque wrenches are the best method to ensure the proper amount of torque is being applied to a wheel nut.

⚠ CAUTION



EXPLOSIVE FORCE HAZARD

To prevent injury due to possible dangerous separation of wheels from the axle, the wheel nuts must be maintained at the proper torque levels. Properly tightened wheel nuts prevent loose wheels and broken studs.

2. Tighten the wheel nuts in three stages.
 - First stage: 20 to 25 foot pounds.
 - Second stage: 50 to 60 foot pounds.
 - Third stage: 90 to 120 foot pounds.
3. Tighten the wheel nuts in a clockwise, cross-axle alternating pattern.

10.11 AXLE BOLTS AND FRAME HOLD-DOWN BOLTS

Check the torque on the axle/frame bolts at least once per year.



Check the torque on the frame hold-down bolts at least once per year. Tighten the bolts to 40 ft-lbs.



10.13 SERVICE CHECKS

10.13.1 Daily (8 Hours)


WARNING



FIRE HAZARD

Gasoline is a highly combustible fuel. Improper use, handling, or storage of gasoline can be dangerous. Never touch or fill a hot engine. **DO NOT** fill the engine's fuel tank near an open flame while smoking or while engine is running. **DO NOT** fill tank in an enclosed area with poor ventilation. Wipe up spills immediately.

1. Check engine oil level (1) and fill, as needed.
2. Check engine fuel level and fill, as needed.
3. Check reduction case fluid level (2) and fill, as needed.



4. Test trailer break-away system.
5. Initially check wheel bolt torque at 10, 25, and 50 miles.
6. Check drive belt for proper tension and tracking.

10.13.2 Weekly (50 Hours)

1. Clean or replace the foam filter element. Replace the paper air filter, as required.



2. Check the tension on the delivery belt. Adjust tension if needed.
3. Check the tire pressure. Inflate the tires to the recommended pressure stated on the tire.

10.13.3 Annually (400 Hours)

1. Check wheel bolt torque.
2. Repack the wheel bearings and check for excessive end play in the bearings.
3. Check frame and trailer hold-down bolts.
4. Thoroughly clean the seed tender.
5. Check the tires for wear, and replace if needed.

10.14 AXLE MAINTENANCE

10.14.1 First 200 Miles

1. Adjust brakes. Refer to OEM manual for procedure.

10.14.2 3,000 Miles or 3 Months

1. Adjust brakes. Refer to OEM manual for procedure.
2. Check torque on wheel nuts. Refer to the section in this manual.
3. Inspect tires for wear. Refer to OEM manual for procedure.

10.14.3 6,000 Miles or 6 Months

1. Inspect brake magnets for wear. Refer to OEM manual for procedure.
2. Inspect suspension parts for wear. Refer to OEM manual for procedure.

10.14.4 12,000 Miles or 12 Months

1. Inspect brake lining wear, check brake cylinder for leaks, and inspect brake wiring for damage. Refer to OEM manual for procedure.
2. Grease the wheel bearings and check the hub for wear. Refer to OEM manual for procedure.
3. Inspect grease seal for leakage. Refer to OEM manual for procedure.
4. Inspect springs for any wear or loss of arch. Refer to OEM manual for procedure.

10.15 TIRES

Check the tires for normal and/or abnormal tire wear. Replace tires that are damaged or worn beyond normal tread life. Refer to the axle OEM manual for a Tire Wear Diagnostic Chart.

Replace the tires with Meridian part number 18131 or an equivalent tire:
3T235/80R16
TR643
Load Range E
For Trailer Service Only

10.16 WELDING REPAIRS



Repair welding must be done with care and with procedures that may be beyond the capabilities of the ordinary welder.

Before performing any type of welding repair to the seed tender, contact Meridian for approval.

WARNING



PERSONAL INJURY HAZARD

Repairs or modifications to the trailer, trailer tongue, or trailer hitch can result in serious injury or death should these repairs fail.

IMPORTANT NOTICE

Anyone performing a welding repair should be certified in accordance to the American Welding Society (AWS) standards.

11. OEM LITERATURE

OEM literature can be stored on the seed tender using the document storage tube.



11.2 AXLE

For any questions concerning the Axis Products axle, refer to the OEM manual that was provided with the seed tender. An Owner's Manual and parts listing is provided with the seed tender.

Additional information can be obtained from:
 Axis Products, Inc.
 3403 Reedy Drive
 Elkhart, IN 46514
 Phone: (574) 266-8282

11.1 HONDA® ENGINE

For any questions concerning the Honda® engine, refer to the OEM manual that was provided with the seed tender.

INTRODUCTION

Thank you for purchasing a Honda engine. We want to help you to get the best results from your new engine and to operate it safely. This manual contains information on how to do that; please read it carefully before operating the engine. If a problem should arise, or if you have any questions about your engine, consult an authorized Honda servicing dealer.

All information in this publication is based on the latest product information available at the time of printing. Honda Motor Co., Ltd. reserves the right to make changes at any time without notice and without incurring any obligation. No part of this publication may be reproduced without written permission.

This manual should be considered a permanent part of the engine and should remain with the engine if resold.

Review the instructions provided with the equipment powered by this engine for any additional information regarding engine startup, shutdown, operation, adjustments or any special maintenance instructions.

United States, Puerto Rico, and U.S. Virgin Islands:
 We suggest you read the warranty policy to fully understand its coverage and your responsibilities of ownership. The warranty policy is a separate document that should have been given to you by your dealer.

SAFETY MESSAGES

Your safety and the safety of others are very important. We have provided important safety messages in this manual and on the engine. Please read these messages carefully.

A safety message alerts you to potential hazards that could hurt you or others. Each safety message is preceded by a safety alert symbol and one of three words, DANGER, WARNING, or CAUTION.

These signal words mean:

- ▲ DANGER** You will be KILLED or SERIOUSLY HURT if you don't follow instructions.
- ▲ WARNING** You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.
- ▲ CAUTION** You CAN be HURT if you don't follow instructions.

Each message tells you what the hazard is, what can happen, and what you can do to avoid or reduce injury.

DAMAGE PREVENTION MESSAGES

You will also see other important messages that are preceded by the word NOTICE.

This word means:

- NOTICE** Your engine or other property can be damaged if you don't follow instructions.

The purpose of these messages is to help prevent damage to your engine, other property, or the environment.

© 2005 Honda Motor Co., Ltd. - All Rights Reserved
 37ZaF003
 00107-26F-6030

HONDA

OWNER'S MANUAL
MANUEL DE L'UTILISATEUR
MANUAL DEL PROPIETARIO

GX120 · GX160 · GX200



Click here to save this manual to your computer.

WARNING:
 The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

CONTENTS

INTRODUCTION	1	SEDIMENT CUP	12
SAFETY MESSAGES	1	SPARK PLUG	12
SAFETY INFORMATION	2	SPARK ARRESTER	13
SAFETY LABEL LOCATION	2	IDLE SPEED	13
COMPONENT & CONTROL LOCATION	2	HELPFUL TIPS & SUGGESTIONS	13
FEATURES	3	STORING YOUR ENGINE	13
BEFORE OPERATION CHECKS	3	TRANSPORTING	14
OPERATION	4	TAKING CARE OF UNEXPECTED PROBLEMS	15
SAFE OPERATING PRECAUTIONS	4	RUSE REPLACEMENT	15
STARTING THE ENGINE	4	TECHNICAL & CONSUMER INFORMATION	16
STOPPING THE ENGINE	5	Serial Number Location	16
SETTING ENGINE SPEED	6	Battery Connections for Electric Starter	16
STOPPING YOUR ENGINE	7	Remote Control Linkage	16
THE IMPORTANCE OF MAINTENANCE	7	Carburetor Modifications for High Altitude Operation	16
MAINTENANCE SAFETY	7	Oxygenated Fuels	17
SAFETY PRECAUTIONS	7	Emission Control System Information	17
MAINTENANCE SCHEDULE	7	Air Index	18
REFUELING	8	Specifications	18
ENGINE OIL	8	Tuneup Specifications	18
Recommended Oil	8	Quick Reference Information	19
Oil Level Check	9	Working Diagrams	19
Oil Change	9	CONSUMED INFORMATION	20
REDUCTION CASE OIL	9	Distributor/Dealer Locator	20
Recommended Oil	9	Information	20
Oil Level Check	9	Customer Service Information	20
Oil Change	10		
AIR CLEANER	10		
Inspection	10		
Cleaning	11		

Additional information can be obtained from:

United States Power Equipment Division
 Customer Relations Office
 4900 Marconi Drive
 Alpharetta, GA 30005-8847
 (770) 497-6400

Honda® Canada, Inc.
 715 Milner Avenue
 Toronto, ON M1B 2K8
 (888) 946-6329

12. TROUBLESHOOTING

12.1 TROUBLESHOOTING CHART

PROBLEM	CAUSE	SOLUTION
Engine will not start.	No fuel.	Fill the fuel tank.
	Low engine oil.	Fill the crankcase with oil.
	Cold engine.	Open choke.
	Ignition key switch off.	Turn ignition key switch on.
	Battery dead.	Recharge or replace battery.
	Engine problem.	Refer to engine manual.
Auger will not start.	Not rotating,	Start engine and increase speed above 1400 RPM.
	Drive pulley connection or auger coupling.	Repair or replace.
	Drive belt slipping.	Increase belt tension.
	No hydraulic oil in reduction case.	Check oil level.
	Failed centrifugal clutch.	Replace clutch.
Electrical functions are not working properly.	Battery cable or battery.	Check battery cable and make sure battery is fully charged.
	Improper ground.	Check for proper grounding of electrical circuit.
Remote throttle doesn't work.	No input power.	Check charge of battery. Recharge or replace, as required.
		Check connections in the remote throttle harness. Be sure connectors are clean and terminals are firmly pushed together.

13. WARRANTY

13.1 WARRANTY STATEMENT

Limited Materials and Workmanship Warranty For Bulk Seed Tenders

Meridian Manufacturing Group (hereinafter referred to as the Manufacturer) hereby warrants the Bulk Seed Tender(s) sold by it to be free from any defect in material or workmanship under normal use and service for a period of one (1) year from the date of shipment. The Manufacturer's obligation under this warranty shall be limited to the repair or replacement only, FOB the original point of shipment, of any defective parts or portions of the seed tender or accessories manufactured by Meridian. Any warranty claim must be reported to the Manufacturer within one (1) year from the date of shipment.

THIS WARRANTY IS SUBJECT TO THE FOLLOWING LIMITATIONS, PROVISIONS AND CONDITIONS:

1. This warranty does not apply:
 - a) To any product sold by the Manufacturer where it is used in areas exposed to corrosive or aggressive conditions including salt water, acids, alkaloid, ash, cement dust, animal waste or other corrosive chemicals from either inside or outside the bin.
 - b) For failures or defects arising out of damage during shipment or during storage on site.
 - c) To materials replaced or repaired under this warranty except to the extent of the remainder of the applicable warranty.
 - d) To damage resulting from misuse, negligence, accident or improper site preparation by others.
 - e) If the product has been altered or modified by others.
 - f) If in the case of coating failures the failure is the result of damage, lack of proper maintenance or failure to remove road salt or other contaminants that may have come in contact with the bin surface.
 - g) To loss of time, inconvenience, loss of material, down time or any other consequential damage.
 - h) For a function that is different than original designed intent.
2. The obligation of the Manufacturer under this warranty shall not arise unless the Manufacturer is notified and this warranty is presented together with a written statement specifying the claim or defect within thirty (30) days after the failure is first detected or made known to the owner and within one (1) year from the shipment date. The Manufacturer in its sole discretion shall determine if the claim is valid and whether correction of the defect or failure shall be made by repair or replacement of the materials.
3. The coating warranty is based on the manufacturer's performance specification for Polyester Powder finishes and does not include repair of minor blemishes or rusting that is normally part of the general maintenance of the seed tender. This warranty does not cover excessive wear on interior coatings. See attachment for full Performance Specification details on Polyester Powder Finishes.
4. The obligation of the Manufacturer hereunder extends only to the original owner and to the Meridian dealer to whom the materials may have been initially sold. This warranty shall not be subject to any assignment or transfer without the written consent of the Manufacturer.
5. The customer shall acknowledge that it has made its own independent decision to approve the use of the supplied materials and also the specific fabrication and construction procedures utilized to complete the seed tender, and has satisfied itself as to the suitability of these products for this particular application.
6. The foregoing sets forth the only warranties applicable to said materials and said warranties are given expressly and in lieu of all other warranties, expressed or implied, statutory or otherwise, of merchantability or fitness for a particular purpose and all warranties which exceed or differ from said warranties herein are disclaimed by the Manufacturer.
7. The owners sole and exclusive remedy against the Manufacturer shall be limited to the applicable warranty set forth herein and the endorsements, if any, issued together with this document and no other remedy (including but not limited to the recovery of assembly or disassembly costs, shipping costs, direct, incidental, special, indirect or consequential damages for lost profits, lost sales, injury to person or property or any other loss, whether arising from breach of contract, breach of warranty, tort, including negligence, strict liability or otherwise) shall be available to the owner or Meridian Dealer or any other person or entities whether by direct action or for contribution or indemnity or otherwise.
8. The financial obligation of the Manufacturer under this warranty shall be limited to the repair or replacement of the product as originally supplied and in no event shall exceed the original cost of the product supplied.
9. The Manufacturer shall not have any obligation under any warranty herein until all accounts for materials, installation and erection of the said product thereof and for labor and other work performed by the Manufacturer or its dealers have been paid in full by the owner.

Warranty Claim Procedure

1. Registering product with Meridian Manufacturing.
2. Contact the dealer unit was purchased from upon discovery of any defects.
3. A completed warranty claim form submitted by dealer to Meridian warranty representative for review and course of action.
4. Warranty repair work will only be performed by Meridian, the dealer or an approved representative. No warranty work completed prior to approval. Failure to follow procedure may affect any or all reimbursement.
5. Claims will be adjudicated at the sole discretion of the manufacturer and in accordance with the terms and conditions of the applicable limited warranty.
6. A complete list of warranty procedures can be procured from the Warranty Department or found in your owner's manual.


Effective July 1, 2009

14. PARTS

The following pages contain a list of serviceable parts for the Titan II Seed Tender unit.

Parts are available from your authorized Dealer Parts Department.


14.1 TITAN II SEED TENDER



1	4	22126	Pin, Bent, 1/2 x 4"
2	4	19236	Pin, Spring, Zinc, 5/32 x 1"
3	4	19594	Pin, Hairpin Cotter
4	2	14020	Lid, Plastic
5	2	19577	Bolt, Hex, Flanged, 3/8-16 x 3/4"
6	2	19564	Nut, Hex, Flanged, 3/8-16
7	1	21036	Bracket, Flex Spout
8	1	22023-01	Plate, Lock-Down
9	1	22023	Plate, Lock-Down


10	4	19956	Decal, Warning, Pinch Point
11	2	19133	Bumper, Rubber with Washer
12	2	19560	Bolt
13	2	19126	Nut, Lock
14	1	36517	Frame, Assembly
15	8	22135	Pin, Headed, 1/2 x 3-1/2"
16	8	19237	Pin, Spring, 5/32 x 3/4"
17	4	14575	Bolt, 1/2-13 x 1-1/2"
18	4	19595	Nut, 1/2-13

14.2 TITAN II SEED TENDER FRAME



1	2	21319	Strap, Rubber
2	1	21286	Battery, SP30
3	1	18657	Cable, Battery
4	3	19540	Nut, Lock
5	1	18128	Holder, Manual
6	3	19578	Bolt, Hex
7	1	19404	Bushing, Nylon 1"
8	2	19568	Bolt, Hex, Flanged, 5/16-18 x 3/4"
9	2	19318	Nut, Hex, Flanged, 5/16-18
10	1	21255	Motor, Honda 5.5 Hp Electric Start
11	4	19626	Bolt, Hex, Flanged, 3/8-16 x 1-3/4"
12	4	19348	Washer, Flat, 3/8"
13	4	19347	Nut, Lock, 3/8-16 Nylon
14	1	21251	Pulley, 3" Honda Drive
15	1	21261	Key, Square
16	1	19356	Bolt, Hex, 1/2-13 x 2"
17	3	19372	Washer, 1/2"
18	1	21253	Pulley, Idler, 5"
19	1	21079-01	Bracket, Idler Pulley Mount
20	2	19572	Bolt, Hex, Flanged, 3/8-16 x 3-1/2"
21	1	22105	Guard, Belt
22	1	19127	Nut, Hex, 1/2-13 Nylon
23	1	21079-02	Spacer, Idler Pulley Bracket
24	2	19564	Nut, Hex, Flanged, 3/8-16
25	1	19937-01	Decal, Warning, Entanglement Hazard
26	1	19447	Grip, Handle
27	2	22031	Handle, Slide Gate
28	2	19128	Nut, Hex, 1/4-20 Nylon
29	2	19307	Washer, 1/4"
30	2	19560	Bolt, Hex, 1/4-20 x 3/4"
31	1	22020-01	Gate, Slide, Left Side
32	1	22020	Gate, Slide, Right Side
33	32	19597	Screw, Self Drill, 1/4-14 x 3/4"
34	1	22147	Seal, Box Top Deck, Titans
35	4	19956-01	Decal, Warning, Pinch Point Hazard
36	1	19934	Decal, Caution, Read and Understand
37	1	19984	Decal, Product Serial Number
38	1	19944	Decal, Notice, Product Warranty
39	1	19931	Decal, Push to Open
40	1	19989	Decal, Warning, Pinch Point Hazard
41	1	18433	Decal, Warning, Electrocutation Hazard
42	1	19935	Decal, Warning, Crush Hazard

14.3 TITAN II ENGINE AND ACTUATOR




T2-0756

1	1	19560	Bolt, Hex, 1/4-20 x 3/4"
2	1	21425	Plate, Actuator Cover
3	1	19307	Washer, 1/4"
4	1	19128	Nut, Hex, 1/4-20 Nylon
5	1	21438	Actuator
6	3	19628	Screw, Round Head, #8-36 x 1"
7	20	19629	Washer
8	3	19630	Nut, Hex, #8-36
9	1	21270-01	Nut, Push, 7/32"
10	1	21437	Spring, Actuator
11	1	21270	Holder, Throttle Cable Wire
12	1	21255	Motor, Honda 5.5 Hp Electric Start

13	2	19343	Nut, Hex, 3/8-16
14	1	38511	Bracket, Actuator Assembly
15	1	19330	Bolt, Hex, 3/8-16 x 3"
16	4	19347	Nut, Lock, 3/8-16 Nylon
17	4	19348	Washer, Flat, 3/8"
18	4	19626	Bolt, Hex, Flanged, 3/8-16 x 1-3/4"
19	1	19991	Decal, Recharge Battery
20	1	36106	Harness, Lower Actuator
21	1	21251	Pulley
22	1	21261	Key, 1/4" x 2"
23	1	21112	Belt, Drive BB92

14.4 TITAN II UPPER AUGER TUBE




T2-0758

1	1	19284	Pin, Spring, 3/16" x 1-1/8"
2	1	36010	Tube, Fold Over Auger Assembly
3	4	19318	Nut, Flanged, 5/16-18
4	4	19309	Bolt, Hex, 5/16-18 x 3/4"
5	1	19447	Grip, Handle
6	1	22106	Tube, Fold Over Handle
7	1	19123	Latch, Fold Over Auger
8	1	21319	Strap, Rubber
9	1	21223	Pin, Hinge
10	1	21407	Shock, Lift Assist (250 lb. Capacity)
11	1	21445	Cable, Auger Alignment
12	1	21333-02	Shaft, Top Auger Bottom Drive

13	1	19405	Bushing
14	1	18714	Auger, Top Assembly
15	1	21453	Shaft, Auger Tail
16	1	21222-03	Cap, 6" Top Bearing
17	3	19586	Nut, Lock, 5/16-18 Nylon
18	2	21259	Flange, Bearing 52 mm Zinc
19	1	21258	Bearing
20	1	19315	Bolt, Carriage, 5/16-18 x 3/4"
21	2	19582	J-Bolt, 1/4-20 x 1-1/2"
22	2	19307	Washer, Flat, 1/4"
23	2	19308	Washer, Lock, 1/4"
24	2	19305	Nut, Hex, 1/4-20


14.5 TITAN II LOWER AUGER TUBE



1	1	19283	Zerk, Grease
2	1	19935	Decal, Warning, Crush Hazard
3	1	19989	Decal, Warning, Pinch Point
4	1	18849	Plug, Square Head, 1/4" NPT
5	1	21136-00	Flighting, Bottom Auger Assembly
6	1	18713	Auger, Bottom Assembly
7	1	21261	Key, Drive
8	1	21452	Shaft, Bottom Auger Drive
9	1	36504	Door, Clean Out

10	1	19936	Decal, Warning, Entanglement Hazard
11	1	21257	Latch
12	1	21322	Pulley, 10"
13	3	19586	Nut, Lock, 5/16-18 Nylon
14	1	21258	Bearing
15	2	21259	Flange, Bearing, 52 mm Zinc
16	3	19315	Bolt, Carriage, 5/16-18 x 3/4"
17	1	18433	Decal, Warning, Electrocution Hazard


14.6 TITAN II THREE TIER SPOUT



1	3	21433	Clamp, Hose, 6"
2	1	36031	Boot Assembly
3	1	38530	Spout, Three-Tier
4	1	36106	Harness, Wire

5	1	38503-01	Cord, Coiled
6	1	21240-04	Throttle Handle
7	1	14002	Harness, Wire, Pigtail with Switch

14.7 TITAN II TRAILER



T2-0754

1	2	19225	Chains, Safety with Hook
2	1	19597	Screw, Self Tapping, 1/4-14 x 3/4"
3	1	22910	Weldment, Frame
4	1	18164	Jack Stand A-Frame Mount
5	1	19275	Breakaway System, Battery BA10-150
6	4	19142	Nut, Hex Flanged, Mild Steel, #8-32
7	3	18118	Tape, Fender Slip
8	1	18153	Tape, Reflective
9	2	18117	Light, Tail with 10 Diodes (LED STL-78RB)
10	2	28543	Cap, Tube
11	2	19438	Plug
12	2	19274	Mud Flap
13	8	19629	Washer, Flat, 5/32"

14	8	19779	Screw, Self Drilling, #8-18 x 3/4"
15	8	18097	Washer, Narrow, 3/4"
16	8	19396	Washers, Helical Spring Lock
17	8	19394	Nut, Hex, Mild Steel, 3/4-10
18	8	19388	Bolt, Hex, 3/4-10 x 2"
19	2	18151	Light, Amber Clearance
20	4	19141	Screw, #8-32 x 5/8"
21	1	19937-02	Decal, Danger, Rotating Part Hazard
22	2	18193	Axle, 7,000 lbs.
23	4	18131	Tire, ST235/80R16
24	32	18991	Nut, Lug, 9/16-18
NS	1	14017	Harness, Wiring

NOTES

NOTES



EXPERIENCE THE ADVANTAGES OF MERIDIAN BUILT STORAGE SOLUTIONS



AGRICULTURAL



INDUSTRIAL



OIL & GAS

Camrose Office
4232 - 38 St.
Camrose, AB T4V 4B2
PH: 780.672.4516
TF: 800.830.2467
FX: 780.672.4759

Lethbridge Office
3125 - 24 Ave. N.
Lethbridge, AB T1H 5G2
PH: 403.320.7070
TF: 800.661.1436
FX: 403.320.7579

Storm Lake Office
2902 Expansion Blvd.
Storm Lake, IA 50588
PH: 712.732.1780
TF: 800.437.2334
FX: 712.732.1028

Winkler Office
Box 760, 275 Hespler Ave.
Winkler, MB R6W 4A8
PH: 204.325.7883
TF: 800.665.7259
FX: 204.325.5556

MERIDIAN
MANUFACTURING GROUP

www.meridianmfg.com